






19. Wiring Diagrams





After '94:



SWITCH CONTINUITY

ENGINE STOP SWITCH	STARTER SWITCH	IGNITION SWITCH	TURN SIGNAL SWITCH	DIMMER SWITCH	HORN SWITCH	LIGHT/NEG SWITCH	PASSING SWITCH
IG BAT2	ST BAT4 HL	FAN IG BAT1	W R L	HL LO HI	HO BAT5	BAT3 TL BAT4 HL	BAT4
OFF	FREE	ON	R	LO	FREE	*	FREE
RUN	PUSH	OFF	N	(N)	PUSH	P	PUSH
		LOCK	L	HI		H	

METER LIGHT
12 V 1.7 W x 4



BI	BLACK	Br	BROWN
Y	YELLOW	O	ORANGE
Bu	BLUE	Lb	LIGHT BLUE
G	GREEN	Lg	LIGHT GREEN
R	RED	P	PINK
W	WHITE	Gr	GRAY